



A publication of Tucker Sno-Cat® Corporation
NO SNOW TOO DEEP

Made in the USA since 1942
NO ROAD TOO STEEP

April 2010 Volume 2 Issue 4

TRAILER LOADING AND TIE DOWN



Proper cargo weight distribution is essential to safe towing of any trailer.

STEP 1.

When loading our vehicles onto our trailers drive forward so the transfer case is just in front of the trailer's front axle, this will insure proper weight distribution and tongue weight.



STEP 2.

Now position the vehicle so the front edge of the blade push frame rests on the center of the trailer blade support.

STEP 3.

Next hook the tie down straps, in an X pattern, over the carrier stops and tighten down, both front and rear.

STEP 4.

Next fold up the ramps and fasten with supplied safety chains.



PLEASE NOTE SOME STATES MAY REQUIRE THE BLADE TO BE TIED DOWN SEPARATELY AND IF NEEDED ANCHOR POINTS ARE ATTACHED IN THE FRONT BASKET AREA.

Tucker Sno-Cat® Corporation

2872 S. Pacific Hwy

Medford, OR 97501

www.sno-cat.com

(541) 779-3731

Toll Free (866) 766-2281