



A publication of Tucker Sno-Cat® Corporation  
NO SNOW TOO DEEP


Made in the USA since 1942  
NO ROAD TOO STEEP

## Welding on the Sno-Cat®


May 2010 Volume 2 Issue 5

Whenever welding is done on the Sno-Cat® always disconnect the batteries and ECM (engine control module). ECM's are sensitive to high voltage and could be damaged if not disconnected. The ECM is located on the passenger side of a rear engine machine and the driver side on a front engine machine.

ECM LOCATION ON CUMMINS TIER 3 ENGINE



ECM LOCATION ON CUMMINS TIER 2 ENGINE



## Summer Service Notice

Please call as soon as possible to schedule your SUMMER SERVICE. The schedule is starting to fill up and longer you wait the tougher it is for us to complete your service before that first snow.

Tucker Sno-Cat® Corporation  
2872 S. Pacific Hwy  
Medford, OR 97501

[www.sno-cat.com](http://www.sno-cat.com)  
(541) 779-3731  
Toll Free (866) 766-2281